Parental controls guide

Parental Controls information

Type of guide

Smartphones and other devices

Features and Benefits

You can enable restrictions to stop your children from using specific features and applications on the Amazon Fire HD, including the ability to prevent purchases from content stores, access to age-restricted videos and movies and access to the camera.

What specific content can I restrict?








What do I need?

An Amazon Account (email address and password).

Step by step guide

Swipe down from the top of the screen and then tap Settings.


Tap Parental Controls.



Step by step guide


2

Tap On next to Parental Controls.




Step by step guide

With Parental Controls turned on, enter a password, confirm your password and then tap Submit.




Step by step guide

Creating and setting up an Amazon Household Account Log into your Amazon account.




Step by step guide

5 Under 'Accounts and Lists' click 'Your Account'



Step by step guide

Under 'Shopping programmes and rentals' click 'Amazon Household'



Step by step guide


7 Click 'Add a child'



Why create an Amazon Household?


Step by step guide

8 Enter the details of your child.




Step by step guide

Click on 'Manage Your Content and Devices' to control what purchased content your child can access and on what device.



Step by step guide


Add a pin/disable voice purchasing to prevent unauthorised purchases Open the Alexa App or echo.amazon.com on your smartphone and tap the menu icon.



Step by step guide



Tap settings and scroll down until you find 'Voice Purchasing'



Step by step guide

Add a 4-digit pin and tap save to set up the pin. Alternatively, you can disable voice purchasing altogether by changing the setting on this page.

